

3M Nomad Carpet Matting 8850

地毯型吸水除泥地墊

3M8850採用專利技術，將粗細兩種不同直徑的纖維編織而成。其中較粗的防彎折聚丙烯纖維可將塵土刮除並隱藏在地墊內部，較細的尼龍纖維則可將鞋底水份順利吸收移除，極適合作為整套3M入口地墊系統最後一道防線。

產品特色：

- 適合每年100萬人次通行的場地。
- 專利技術將聚丙烯纖維與尼龍纖維編織成穗狀結構，具有卓越的除塵與吸水效果。
- 不規則形狀的編織紋路具有優美外觀，並可將砂土塵沙隱藏在編織紋路中，留待日後清理。
- 以特殊溶液染整處理的纖維可有效防止退色或沾污，使地墊長保美觀。
- 乙烯材質背襯使地面無遭受沾污之虞，並使地墊內部蓄積的塵土與水份不至於與地面直接接觸。
- 低隆起設計不但不影響步行，亦使推車、輪椅得以在地墊上順利移動。
- 即使在頻繁的通行條件與經常清理的狀況下，仍可長期維持良好的外觀。



紅色



棕色




綠色



灰色



藍色



黑色



Technical Data/ Product Specifications



Nomad™

Carpet Matting 8850

(Formerly 3M™Enhance™ Matting 850)

1.0 Product Description

The product is a looped-pile, carpet-type entryway matting. 3M™ Nomad™ Carpet Matting 8850 features a unique tufted construction with random pattern design utilizing two different size fibers. Areas of large diameter polypropylene fibers combine with areas of small diameter nylon fibers to maximize dirt removal, water pick up and holding capacity. The matting has a solid vinyl backing and edging on all four sides.

2.0 Intended Use

For use as entryway matting where snow, water and/or dirt tracking is a problem.

3.0 Standard Sizes

Standard mats with 4-side edging:

2 feet x 3 feet, 3 feet x 5 feet, 3 feet x 10 feet, 4 feet x 6 feet, 4 feet x 8 feet, 4 feet x 10 feet and 6 feet x 10 feet

(0.6m x 0.9m, 0.9m x 1.5m, 0.9m x 3.0m, 1.2m x 1.8m, 1.2 x 2.4m
1.2m x 3.0m and 1.8m x 3.0m)

Custom lengths with 4-side edging:

Widths: 3 feet, 4 feet or 6 feet

(0.9m, 1.2m and 1.8m)

Lengths: 2 feet to 60 feet in 1-foot increments

(0.6m to 18.2m in 0.3m increments)

Custom cuts with 4-side edging:

Widths: 2 feet to 11.5 feet (0.6m to 3.5m)

Lengths: 2 feet to 60 feet (0.6m to 18.2m)

4.0 Colors

Ebony, Slate (gray), Dove (brown), Checkers (gray/red mix),
Blueberry, Burgundy, Spruce

5.0 Requirements

The product is made of two different sizes of fibers featuring a unique tufted construction and random pattern design; small diameter nylon fibers combined with large diameter polypropylene fibers to maximize performance. The product has a black solid vinyl backing and edging on four sides.

Detailed Requirements:

<u>Property</u>	<u>Typical Values</u>	
Thickness ASTM D418-68	Minimum: 0.32 inches (8.1 mm)	
Weight ASTM D-418	Minimum: 6.5 lb/yd ² (3.5 kg/m ²)	
Flammability DOC FF 1-70 (Pill Test)	Passes	
Electrostatic Propensity AATCC 134, Neolite soles	<u>Step</u> -1.88 KV	<u>Scuff</u> -1.38 KV

6.0 Packaging and Marking

Packaging	Pre-Cut Mats – one per case except 2 ft. x 3 ft. (6 per case)
Marking	Each carton shall be marked with product name, size, color and manufacturer's trade name.

7.0 Installation, Seaming and Edging

Custom Cutting

3M™ Nomad™ Carpet Matting 8850 can be easily custom cut without edges fraying. Length and width dimensions may change during use. Wall-to-wall installations are not recommended.

Tools needed:

- Utility knife
- Straight edge, 3-4 feet (1.1.3m) long
- If matting is to be cut to close specifications, be certain it is relaxed and not stretched. Unroll matting and allow to lie undisturbed for 24 hours at room temperature.
- Use a utility knife and straight edge for cutting. Do not use scissors.
- If it is necessary to move matting after cutting, roll it loosely to avoid stretching.

Seaming:

3M™ Nomad™ Carpet Matting 8850 can be seamed together to make mats wider or longer than standard sizes.

Materials needed:

- 3M™ Matting Seaming Tape (kit or roll)
- 3M™ Matting Adhesive (one 3-ounce tube of adhesive will seam 15 linear feet [4.5 meters] of matting)

7.0 Installation, Seaming and Edging (continued)

- Before seaming, be certain that matting is relaxed and not stretched. Unroll matting and allow to lie undisturbed for 24 hours at room temperature. Avoid stretching or pulling on mat when seaming.
- Use pieces from the same roll to assure that color, shade and texture are the same.
- Maximum recommended mat size is 80 sq. ft. (7.2 sq. meters).

You may want to use smaller mats for ease of handling and maintenance.

1. Place pieces of matting to be seamed side by side on a clean surface.
2. Unroll 3M™ Matting Seaming Tape between the two pieces of matting to be joined. Cut tape to length.
3. Position the pieces of matting on the seaming tape so that each piece's edge covers half the width of the tape. Be sure the pieces of matting touch at the tape center but do not overlap or buckle.
4. Fold back the edge of one piece of the matting along the full length of the seam.
5. When applying adhesive work rapidly. Adhesive may cause wrinkling of the seaming tape if the matting is not joined within 5 minutes of applying the adhesive. Apply adhesive in a continuous "zig-zag" pattern staying 1/4" (6 mm) from the outside edge of the exposed half of the seaming tape.
6. Return the folded edge of the matting to its original position and apply moderate pressure to bond the adhesive.
7. Fold back the second piece of matting along the full seam length.
8. Apply two additional beads of adhesive, the first along joint of seaming tape and the first piece of matting, and the second in a wavy pattern 1/4 inch (6mm) from the outside edge of the exposed half of the seaming tape.
9. Return the folded back edge of the matting back to its original position and press firmly. At the same time, gently push both pieces of matting together to eliminate any gaps.
10. Place a weight, such as a board, along the full length of the seam to maintain pressure on the bond. Allow to dry undisturbed for at least eight hours before placing it into service.

Applying Matting Edging:

Edging can be easily applied to 3M™ Nomad™ Carpet Matting 8850 to form a tapered edge.

Tools and Materials Needed:

- Utility knife
- Straight edge, 3-4 feet long (1-1.3 meters)
- 3M Matting Edging – Medium Profile
- 3M Matting Adhesive (one 3-ounce tube of adhesive will apply approximately 15 linear feet of edging.)

7.0 Installation, Seaming and Edging (continued)

- Before applying edging ensure that matting and edging are relaxed and not stretched. Unroll matting and edging and allow to lie undisturbed for 24 hours at room temperature. Do not stretch or pull on matting when applying edging.
 - Apply edging to opposite side of matting where most people will walk. Recommended maximum edge length is 12 feet (4 meters).
1. Arrange mat on floor so that sides to be edged are straight. Trim edges with a utility knife (not scissors) and a straight edge if necessary (see Custom Cutting).
 2. Cut a piece of edging the same length as the edge of mat.
 3. Place edging flat on the floor, grooved side up.
 4. Apply two beads of adhesive liberally to the top of edging.
 5. Place edge of mat on top of edging groove containing adhesive. Gently work mat snugly into the corner of edging groove to ensure a good fit.
 6. Place a weight, such as a board, along the full length of edging to maintain pressure on the bond. Allow to dry undisturbed for at least 8 hours before placing it into service.

8.0 Cleaning and Maintenance

Daily Maintenance

Vacuum daily.

Use an upright beater-brush dry vacuum adjusted to its most powerful setting. Move nozzle slowly over mat to allow time for dirt to be picked up.

In heavier traffic areas or at pivot points, rotate matting end for end when repositioning.

Important: Keeping the backing of the mat clean is critical in minimizing the mat “walking”. Floor under mat must also be kept clean (swept and/or damp mopped underneath mat).

Weekly Maintenance:

1. Remove matting from service.
2. Turn matting over and run beater bar, dry vacuum on back side of matting.
3. Pick up matting.
4. Clean up dirt/debris from floor (sweep, vacuum, damp mop, etc.)
5. Place matting back in service and vacuum top surface of matting.

Wet Conditions for Mats and Rolls:

1. Use an extractor or wet vacuum to remove as much water as possible from mat.
2. Allow mat to dry. Hang up if necessary. Use of fan or blower will reduce dry time.

Restorative Maintenance:

Frequency of restorative maintenance will depend on the amount of traffic and soil in the area of application.

1. Wet matting with diluted solution of 3M™ Carpet Pretreatment or 3M™ Carpet Extraction Cleaner.
2. Loosen dirt using a rotary brush.
3. Extract at least two times. (If heavily soiled, repeating this procedure may be required.)
4. Let mat dry.

**8.0 Cleaning and Maintenance
(continued)**

OR

High Pressure Washer

Use high pressure washer (i.e., at self-service car wash).

1. Hang mat up.
2. Wash mat thoroughly.
3. Rinse mat thoroughly.
4. Let mat dry.

**9.0 Weight and Cube
per Case**

<u>Size</u>	<u>Approximate Weight</u>	<u>Cube</u>
2 ft. x 3 ft. (6/case)	28 lb.	2.9 cu. ft.
3 ft. x 5 ft.	15 lb.	0.9 cu. ft.
3 ft. x 10 ft.	29 lb.	1.7 cu. ft.
3 ft. x 20 ft.	48 lb.	2.7 cu. ft.
3 ft. x 30 ft.	69 lb.	3.8 cu. ft.
3 ft. x 60 ft.	137 lb.	9.4 cu. ft.
4 ft. x 6 ft.	21 lb.	1.6 cu. ft.
4 ft. x 8 ft.	27 lb.	2.3 cu. ft.
4 ft. x 10 ft.	33 lb.	3.5 cu. ft.
4 ft. x 20 ft.	65 lb.	3.5 cu. ft.
4 ft. x 30 ft.	90 lb.	4.9 cu. ft.
4 ft. x 60 ft.	179 lb.	9.4 cu. ft.
6 ft. x 10 ft.	47 lb.	3.3 cu. ft.
6 ft. x 20 ft.	90 lb.	6.8 cu. ft.
6 ft. x 30 ft.	134 lb.	9.2 cu. ft.
6 ft. x 60 ft.	270 lb.	15.3 cu. ft.